


1-4620 1-4621 1-4624 (-01~-05) 概略寸法表



	A	B内寸	C内寸	D	E	H	R内寸
*-01	40	46	55.46	40	32	70	3
*-02	51	59	69.84	49	34.92	82.8	4
*-03	55	65	78.19	55	44	95.8	5
*-04	66	77	91.6	64	51	109.8	6
*-05	82	94	110.9	77	61.5	148	6

単位 mm